




# DATA ACQUISITION

- Data acquisition
- Continuous-time sinusoidal signals
- Sampling a continuous-time signal
- Quantization
- Analog to Digital (A/D) and Digital to Analog (D/A) conversion
- Sampling a sinusoid – aliasing
- The Nyquist sampling theorem
- Relations among frequency variables
- (Reconstructing continuous-time signals)

# Data acquisition

- **Data acquisition** typically consists of three stages:
  - \* **Transduction** (in general conversion of one form of energy to electrical energy which is suitable for encoding into a computer)
  - \* **Analog signal conditioning** (amplifying and filtering the analog signal measured with a transducer to provide a good match between the typically low-amplitude, wide-bandwidth transducer signals and the analog-to-digital converter)
  - \* **Analog-to-digital converter** (transforms a continuous-time signal into a digital signal: sampling - taking amplitudes of continuous-time signal at the discrete times, quantization - sample amplitudes can only take a finite set of values)



# Continuous-time sinusoidal signals

- Cosine signal

$$x_a(t) = A \cos(\Omega t + \theta), \quad -\infty < t < \infty$$


$A$  is the amplitude

$\Omega$  is the frequency in radians per second [rad/s],  $\Omega = 2 \pi F$

$\theta$  is the phase in radians [rad]

$T_p$  is the duration of one cycle in seconds [s]

$F = 1 / T_p$  is the frequency in cycles per second or Hertz [Hz],  $\text{Hz} = 1/\text{s}$




# Sampling a continuous-time signal

- **Discrete-time signals** are obtained by sampling a **continuous-time signal**  $x(t)$  at regular intervals

$$x[n] \triangleq x(nT_s), \quad -\infty < n < \infty$$

$$F_s \triangleq \frac{1}{T_s}$$

- $T_s$  is the **sampling interval** or **sampling period** in seconds [sec], [s]
- $F_s$  is the **sampling frequency** or **sampling rate** in samples per second [smp/s] or in [Hz], [1/s]



# Quantization

- A quantizer takes  $x[n]$  and produces a signal  $x_q[n]$  that can only take a finite number of values
- The quantizer output  $x_q[n]$  is usually equal to the closest integer
- The number of quantization steps is a power of two
- The quantizer encodes signals whose values lie in the range:

$$-V_{max} \leq x[n] < V_{max}$$


- Where  $V_{max}$  is related to the number of quantization steps by:
- and  $B$  is the number of bits of the quantizer

$$V_{max} = 2^{B-1}$$



# Quantization

- $x_q[n]$  as a function of  $x[n]$  for  $B = 4$  corresponding to  $V_{\max} = 8$



# Analog to Digital (A/D) and Digital to Analog (D/A) conversion


- Continuous-time signal,  $x_a(t)$
- Discrete-time unquantized samples,  $x_a(nT)$
- A/D → Discrete-time quantized samples,  $x_q(nT)$
- Output of D/A converter,  $x_q(t)$

$$x_a(nT) \rightarrow x[n]$$

Discrete signal

$$x_q(nT) \rightarrow x[n]$$

Digital signal



[Proakis, Manolakis]

# Sampling a sinusoid - aliasing

- Sampling a continuous-time sinusoid:  $\frac{F}{F_s} = f$


$$x[n] = x(nT_s) = a \cos(2\pi F n T_s + \phi) = a \cos(2\pi n F / F_s + \phi)$$

- $x[n]$  hides a **difficulty** arising from the ambiguity of frequency for discrete-time sinusoids:
  - \* It is not possible to know if the frequency of the original continuous-time signal  $x(t)$  was  $F$ , or  $F + F_s$ , or  $F + 2F_s$ , etc; or,  $F_s - F$  or  $2F_s - F$ , etc
- This phenomenon is known as **aliasing** because frequencies may not be what they appear to be once a continuous-time signal  $x(t)$  is sampled
- **Aliasing** – the error in a signal arising from limitations in the system that generates or processes the signal (Collins English Dictionary)
- $F$  - continuous-time frequency in cycles per second [cyc/s], [Hz]
- $f$  - discrete-time frequency in cycles per sample [cycles/sample], [cyc/smp]





# Sampling a sinusoid - aliasing



# The Nyquist sampling theorem

- How to avoid aliasing?
- Regarding the previous example, what is the minimum number of samples per sinusoid,  $N$ , that would still approximate a sinusoid?  $N = ?$
- Regarding the previous example, what is the highest frequency  $F$  (expressed with  $F_s$ ) of a sinusoid that would still be approximated, if using sampling frequency  $F_s$ ?

Since:  $F_s / F = N$  and  $N \geq 2$ , follows:  $F = F_s / 2$

- If  $F_s = 2.F$ , the  $F_s$  is said to be Nyquist frequency

# The Nyquist sampling theorem


- Sampled analog signal  $x(t)$  should not contain frequencies higher than  $F_s / 2$ ;
- Sampling frequency  $F_s$  should be higher than twice the highest frequency  $F$  present in the analog signal,  $F_s \geq 2 \cdot F$

=> Principal value of discrete-time frequency  $0 \leq f \leq \frac{1}{2}$

# The Nyquist sampling theorem

- In practice always avoid aliasing by **low-pass filtering** the continuous-time signal  $x(t)$  before sampling
- In practice sample signals at about  $F_s = (3-4).F$

## NYQUIST SAMPLING WITH ANALOG LOWPASS FILTER



# Relations among frequency variables


## Lowpass filtering and sampling

$$x_a(t) = A \sin(2\pi F t + \theta)$$

$$= A \sin(\Omega t + \theta)$$

$$\Omega = 2\pi F$$

$$(F_s = 6 \text{ kHz})$$



$$x_a[nT_s] = A \sin(2\pi F/F_s n + \theta) = x[n]$$

$$= A \sin(\omega n + \theta) = x[n]$$

$$\omega = 2\pi F/F_s \rightarrow \omega = 2\pi f$$



$\Omega$ ,  $-\infty < \Omega < \infty$ ,  $\Omega = 2\pi F$ ,  
the frequency in radians per sec [rad/s]

$$F, \quad -\infty < F < \infty,$$


the frequency in cycles per sec or Hertz [Hz]

$$f, \quad -1/2 \leq f \leq 1/2,$$

the frequency in cycles per sample [cyc/smp]

$$\omega, \quad -\pi \leq \omega \leq \pi, \quad \omega = 2\pi f,$$

the frequency in radians per sample [rad/smp]



# (Reconstructing continuous-time signals)

- If a continuous-time signal  $x(t)$  contains no frequency components higher than  $F$ , it can be exactly reconstructed from samples taken at a frequency  $F_s > 2F$
- The Nyquist theorem gives an explicit *interpolation formula* for reconstructing  $x(t)$  from the discrete-time signal  $x[n]$ :

$$x(t) = \sum_{n=-\infty}^{\infty} x[n] \phi(t - nT_s)$$


with a basic function  $\Phi(t)$ :

$$\phi(t) = \frac{\sin(\pi F_s t)}{\pi F_s t}$$

- Time-dependent weights  $\Phi(t - nT_s)$  are obtained by delaying the basic function  $\Phi(t)$

# (Reconstructing continuous-time signals)

- The basic function  $\Phi(t)$ :



- This function verifies the property:

$$\phi(nT_s) = \begin{cases} 1 & \text{if } n = 0 \\ 0 & \text{otherwise} \end{cases}$$

- This property implies that  $x(t) = x[n]$  for  $t = nT_s$
- The signal is said to be sampled at Nyquist frequency if  $F_s = 2F$